User manual CLU Z-Wave CLU-200-E-00


The Common Logic Unit (CLU) module for DIN rail assembly, with 2-Wave wireless commu-nication controller, executes the function of processing logic and storing the configuration. The CLU constitutes the basis for every sys-tem. The CLU module also ensures communi-cation with 10M modules via a local busbar. It expands the communication possibilities of the GRENTON system with a wireless net-work.



1. Technical data

Device power supply	24 V _{dc}
Maximum power consumption	2,4 W
Maximum device current	100 mA (for 24 V _{dc})
TF-bus power supply	24 V _{dc} with current limitation to 1 A
Z-Wave frequency	868 MHz
Maximal radio power	1 mW
Maximal wire cross section	2,5 mm ²
Weight	145 g
Size [DIN]	4
Fixing	electrical box, rail DIN-3 / TH 35 / TS 35
Dimensions (H/W/D)	58/71/90 mm
Operating temperature range	0 to +45 °C

2. Wiring diagram



LINK	button - add Z-Wave devices
UNLINK	button - remove Z-Wave devices
V+	power supply signal
GND	power supply ground signal
Verr	red diode - low voltage of power supply
ON	green diode - on
ERR	red diode - error
Termination	termination connector
TF-Bus	TF-Bus connector

3. Warnings and cautionary statements



A TENTORY Before proceeding with the assembly, read the installation schematics and full instructions available at www.grenton.com.Failure to follow the guidelines contained in the instructions and other requirements of due care valid as a result of the nature of the equipment (device) may be dangerous to life / health, damage the device or installation to which it is connected, damage other property or violate other applicable regu-lations. The manufacturer of the device. Gren-ton Sp. z. o. o. does not bear any responsibility



DANGER !

Danger to life caused by electric current!
The components of the installation (individual devices) are designed to work in a home

4. CE marking

The manufacture declares that the de-vice is in full compliance with the requirements of EU legislation that includes the directives of a new approach appropriate for this equipment. In particular, Grentor Sp. 2 o. declares that the device fulfills the requirements on safety, spec-ified by law, and that it conforms to the national



5. Warranty

Warranty available at: www.grenton.com/warra

Manufacturer contact details

Grenton Sp. z o.o. ul. Na Wierzchowinach 3 30-222 Kraków, Polska (PL) enton.co v.gi

for the damage (property and non-property re-lated) resulting from the assembly and / or use of the equipment not in accordance with the in-structions and / or due diligence in handling the equipment (device). • Device power supply, permissible load or other characteristic parameters have to be in accordance with the device specification, de-scribed in particular in the "Technical data" sec-tion

tion. • The product is not intended for children and

Interplate to not interface to induct and animals.
If you have technical questions or comments about the device operation, contact Grenton Technical Support.
Answers to frequently asked questions can be found at www.support.grentonpl

electrical installation or directly in its vicinity. In-correct connection or use may cause a fire or electric shock. • All work related to the installation of the de-vice, in particular works involving interference in the electrical installation, may be performed only by a person with appropriate qualifications or licences. • When installing the device, make sure that the power supply voltage is disconnected from the circuit in which the device is connected or near which the assembly takes place.

regulations that implement the appropriate di rectives: The Directive on the electromagneti compatibility (EMC - 2014/30/UE) and the Di rective on the limitation of the use of specifi substances in electrical and electronic equip ment (RoHS II - 2011/65/UE).